

## Speakers or Car Adaptor Port

### Important Hints:

- The **Battery Indicator** will appear in the upper corner of the display when battery life is at approximately 20 percent or less.
- For more in-depth information on the features and usage of your new RioVolt SP90, check the electronic **RioVolt User Guide** available for downloading at [www.riohome.com](http://www.riohome.com) under **Support**.
- To find and order accessories available for the RioVolt SP90, such as the carrying case, car kit or remote control, go to [www.riohome.com](http://www.riohome.com) under **Buy**.
- If your RioVolt SP90 gives a **No Disk** error message when spinning up, try the following:
  - Make sure the CD is seated properly.
  - See if a standard audio CD functions properly.
  - Try to play a CD created with standard MP3/WMA files encoded at 128 Kbps, not variable bitrate (VBR) files.
  - Try burning to a different media or brand of media.
  - Try using a CD created on another CD burner.
  - Try burning your CD at a slower rate (say 2x or slower) to see if it makes the files load properly.
  - Try closing the CD volume when you burn the CD.
- If you are using a Macintosh to burn your CDs, make sure the .MP3 extension is at the end of each file. Some versions of Mac software do not include this extension and these files cannot be read by the RioVolt SP90.

**SP** stands for **Electronic Shock Protection**. The RioVolt SP90 reads ahead on the CD to store part of the track so that if the RioVolt SP90 is bumped, the music will continue to play uninterrupted.

### Package Contents

- RioVolt™ SP90
- Earphones
- 2 AA Alkaline Batteries
- Getting Started Poster

### System Recommendations

CD-ROM Writer (RW)


### Technical Support — UK

#### Hours of Operation:

- Mon.-Fri. 8.00 am-19.00 pm GMT
- Saturday 8.00 am-15.00 pm GMT

#### Telephone

+44 (0)870 870 5727



### Display

### WARNING

TO REDUCE THE CHANCE OF SHOCK OR INJURY, DO NOT USE or OPERATE THIS DEVICE IN OR NEAR WATER OR WET LOCATIONS

### CAUTION

RISK OF EXPLOSION, DAMAGE OR BATTERY LEAKAGE IS POSSIBLE IF REPLACED INCORRECTLY OR BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO INSTRUCTIONS OR LOCAL LAWS.

Use only certified and approved Batteries and AC Adaptors those specified in the product User Guide.

Use of earphones while operating a vehicle is not recommended and is unlawful in some areas. Be careful and attentive while driving. Stop operation of the player if you find it disruptive.